



## **Pierce Heated Scraper**

**Model**  
**101, 301, 401**



4685 Runway Street Unit D, Simi Valley, CA 93063  
Phone (805) 864-9255: Fax (714) 447-3531 <https://www.piercebeekeeping.com>

## Introduction

Pierce Beekeeping Equipment LLC has been manufacturing the finest electric uncapping knives and heated scrapers in the world since 1947. This scraper has a much faster heat response time than similar scrapers in the market. Our heater elements are specifically designed for our scrapers.

For more information visit: [www.piercebeekeeping.com](http://www.piercebeekeeping.com)

Pierce Heated Scrapers have a built-in thermostat and are entirely automatic in their heat control. The built in thermostat is designed to operate at 300°F (+/- 15°F). This heated scraper will operate on any 115-120 volt AC power.

**Please read the complete instructions below before using the Scraper.**

## Safety

When using electrical scrapers, basic safety precautions should be followed including the following:

- **Do not use this heated scraper to scrape highly combustible material.**
- Do not touch the hot blade. The hot blade can cause a severe burn.
- Never leave a hot knife unattended.
- To protect against risk of electrical shock, do not put the knife in water or other liquids.
- Do not operate the knife in water or under wet conditions.
- Scraper blade is very sharp, handle it carefully.
- Keep the scraper away from children. Scraper is not intended to be used by children.
- Do not use the scraper if it is damaged or malfunctioning.
- Never use the scraper as a prying tool.
- Never hit objects with the scraper.
- Clean your scraper before and after each use to avoid burning material onto the blade.

## Direction for use

- Plug the clean scraper into a 110-120 volt, grounded electrical outlet.
- Smoke may appear during first use. This is normal.
- Preheat the scraper for approximately 2 to 3 minutes to bring scraper's temperature to equilibrium.
- Now you are ready to use the scraper.
- Start scraping away from the body.
- Be very careful to keep your other hand and all other parts of your body out of the path of the scraper.
- When done using unplug the scraper.
- Carefully clean the scraper. It is easier to clean a warm scraper than hot or cold.
- **Do not immerse the scraper in water.**

## Warranty

If your scraper fails within one year of purchase due to any manufacturers defects we will replace it under our limited warranty provided. You can return the scraper at your expense to us. We reserve the right to inspect and verify that the scraper has not been abused or mistreated or tampered with. This limited warranty is voided if the product appears to have been used improperly, immersed in water, or used as a prying tool. Please return warranty card as proof of purchase within 30 days.

**Thank you**  
***Pierce Team***